



MOUNTING TEMPLATE

Use this template to mount your time clock.

Included are four drywall anchors and four screws, remove them from the package.

Designate a place to hang your new uAttend Staffing Time Clock and line this template up to that area. Using the template as your guide, drill four holes with a 3/32" (2.38mm) drill bit into your wall.

Remove the template and insert the drywall anchors into the wall. Align the mount to the holes and screw it to the wall. Place your time clock onto the mount.